

# Big 12® Speed®Square with patented Layout Bar

## Usage Instructions for OUT OF SQUARE corners.



1. PROBLEM: An out of square corner.



2. SOLUTION: Remove the 2 hex pegs (and bolts) and loosen both Layout Bar wing nuts. Place the Big 12® Speed®Square flush with back wall.



3. While holding the square flat and tight against the back wall, align the Layout Bar flush with the side wall and tighten the rear-most wing nut.



4. Keeping the square in position, tighten the front-most wing nut.



5. Place the now adjusted square on the edge of the countertop and transfer the corrected angle.



6. Stand the Big 12® Speed® Square to mark the back splash.



7. Final markings... ready to be cut.



8. THE RESULT: a perfect countertop fit.